English

BITZEE CAT CAFÉ

WHO WILL YOU FIND IN THE CAFÉ LOUNGE?

COMMON

Cranky Cat

Boss Kitty

Hairless Cat

Snoozy Kitty

Fancy Cat

Magician Cat

Cool Kitty

Scaredy Kitty

Prankster Cat

Villain Cat

RARE

Fashion Cat

Clumsy Cat

Tuxedo Cat

LEGENDARY

Kawaii Kitty

Chonky Kitty

COLLECT ALL 15!

BITZEE™ 5+

TM & © 2026 Spin Master Ltd. All rights reserved.
Bitzee™ Patent information: patents.spinmaster.com

SPIN MASTER

1 GET STARTED



TURN ON
Press and hold B.



EXIT TRY-ME
Press and hold the screen for 3 seconds to exit Try-me.

TURN OFF
Press and hold B for 3 seconds.

2 TUTORIAL

Learn to play with your Bitzee by following the tutorial on screen.

PRESS QUICKLY

SHAKE



PRESS & HOLD (1 SECOND)

PRESS B QUICKLY

TOUCH WITH COIN

Complete the tutorial and you are ready to play!

TAP GOLD EYES WITH GOLD SIDE OF COIN FACING YOU.

3 MAIN MENU



Press B to access Menu and keep pressing to scroll through icons. Press screen to select.

CAFÉ LOUNGE
Press B to scroll through your collection of cats. Tap a cat to play with them.

GAMES
Press to play and unlock games.

LOVE METER
Fill the meter to unlock new cats.

SHOP
Redeem coins you've earned to get café accessories.

CAFÉ MENU
Press to buy your cat treats from the café menu.

SETTINGS
Adjust volume or reset Bitzee.

Press and hold B to exit the Main Menu and return to the home screen.

4 PLAYING WITH BITZEE

FILL LOVE METER - Play with Bitzee to unlock new cats.



PLAY GAMES TO EARN BITZEE COINS - Buy new games or go to the Shop and Café menus to buy treats and accessories for your cats.



5 NEEDS MESSAGES

Your Bitzee will send a message if they need something. Don't ignore these or your Bitzee will run away!

LOVE
Your cat needs love. Press screen to show them love.



FEED
Your cat is hungry. Buy treats from the Café Menu to feed them.





POOP
Your cat pooped. Shake to clean up the poop.

CLEAN-UP
Your cat made a mess! Shake to tidy up.



CUSTOMER
Fill your customer's order by playing a food game. Collect more coins when you win!

6 GAMES

Some games can be unlocked when you earn enough Bitzee coins.

COPY THAT CUPCAKE

Decorate cupcakes just the way your customer ordered them!

- Press B to scroll through cake options, then press screen to select.
- Repeat to add the right frosting and sprinkles.

CATPUCCINO POUR

Make drinks as fast as you can without underfilling or overfilling the cups.

- Press and hold B or screen to fill cup up to the line with coffee.
- Hold B or screen again to add foam, then release when it reaches the line.

STACK-A-SUB

Build sandwiches by catching the falling ingredients, but avoid the junk!

- Press B to move the bread slice directly below the food items as they fall.
- Catch the top bread slice to finish.



SMOOTHIE SLICER

Make as many smoothies as you can in 60 seconds, but avoid junk items!

- Press B to slice fruit as it flies over the blender based on the customer's order.
- Shake to blend and serve.

BOBA BALLISTICS

Fill up your cup with boba, but don't let the rats take them!

- Press B quickly to drop boba into the cup.
- Fire boba at rats to earn more points and stop them from stealing!



KITTY PILE-UP

Arrange cats on the cushion so they all fit without overlapping.

- Press the screen to stop each spinning cat into the ideal position.
- Fewer overlaps mean a higher score.

Tap the coin after each game to collect the Bitzee coins you've earned!

7 SHOPPING

Play games to collect coins that you can spend on food and accessories.

CAFÉ MENU

Press B to scroll through treats you can feed your cats.

Tap coin to buy treat.

ACCESSORIES SHOP

Each accessory pairs with a particular cat. Unlock cats to unlock more accessories.

Press B to scroll through accessories you can get your cats.

Tap coin to add accessory to your café.

TAKE YOUR BITZEE ON THE GO

Use the loop hole at the top of your Bitzee Cat Café to attach your own strap (not included).



SETTINGS MENU

VOLUME
Press screen to change the volume.

GO BACK
Press screen to exit menu.

RESET BITZEE
⚠ CAUTION – THIS ACTION CAUSES A FACTORY RESET AND ERASES ALL EXISTING PLAY HISTORY.

Touch and hold the screen to start the countdown. Do not lift your finger until the countdown finishes and you hear the alarm sound effect. Your Bitzee is now reset to the on-shelf demo.

REPLACE BATTERIES

LOW BATTERY WARNING - Before replacing batteries, turn Bitzee off, or your progress may be lost.



Spin Master Ltd., 225 King Street West, Toronto ON M5V 3M2 Canada
Spin Master International B.V., Kingsfordweg 151, 1043 GR Amsterdam, NL
Spin Master Toys UK Ltd. Meridian House, Fieldhouse Lane, Marlow, Buckinghamshire, SL7 1TB, UK
Spin Master Inc., PMB #10053, 300 International Drive, Suite 100, Williamsville, NY 14221
Spin Master Australia Pty Ltd, Level 9, 205 Pacific Hwy, St Leonards, NSW 2065;
Patent information: patents.spinmaster.com.
TM & © 2026 Spin Master Ltd. All rights reserved.

MADE IN CHINA

T22912_0002_20160306_GEN_QSG_R1

0-3

⚠ **WARNING: CHOKING HAZARD** – Small parts. Not for children under 3 years.